


Fast, easy and convenient, the Auto-Raster<sup>®</sup> Universal *simplifies the process of* inserting Raster<sup>®</sup> spheres.



## AUTO-RASTER® UNIVERSAL



## Auto-Raster<sup>®</sup> Universal

The Auto-Raster<sup>®</sup> Universal Braille dispensing and inserting device is an exciting product that completely automates the process of producing Raster<sup>®</sup> Braille. It is easy to install, requires no special software and fits most computerized routing/engraving machines. The Auto-Raster<sup>®</sup> Universal works with your current computerized router/ engraver, using existing software, to place Raster<sup>®</sup> Braille automatically into sign material substrates.

The Auto-Raster<sup>®</sup> Universal is five times faster than manually placing Raster<sup>®</sup> spheres and 15 times faster than routing Braille. Simply drill the holes and then re-run the same program with the Auto-Raster<sup>®</sup> Universal in place. Raster<sup>®</sup> spheres are automatically dispensed and inserted into the sign material.

Features:

- Easy to install.
- No special software required.
- Fits most existing computerized routing/engraving equipment.
- Accommodates uneven materials up to 3/32 inch and still inserts Raster<sup>®</sup> spheres at the correct depth.

The Auto-Raster<sup>®</sup> Universal makes it easy for you to offer your customers the clean look and feel of Raster<sup>®</sup> Braille.

